

This sheet covers the installation of the VAX Server micro form factor. This system should only be installed by a gualified technician using common hand tools and approved materials in accordance with the National Electrical Code ANSI/NFPA 70, state and local wiring codes.



Rear Panel Connections & Controls

Unpacking and Installation

Unpack the unit and place it in the mounting location. Hard drives are preinstalled from the factory.

- Keyboard and mouse are included with the unit. •
- Connect monitor(s) using the DP and/or HDMI ports (refer to figures above). DP to HDMI adapters are • included as needed.
- Connect unit to the network. Refer to figure above. The port is setup to procure an IP address automatically using DHCP.
- Attach the power cord and power the unit on. It is recommended to use an Uninterrupted Power Supply (UPS) to prevent data loss/corruption and/or drive failures due to sudden power loss.

Vicon part number Product specifications subject to change without notice. Copyright ©2023. All rights reserved. Vicon and its logo are registered trademarks and Valerus and its logo are trademarks of Vicon Industries Inc. 8009-8274-28-00

VICON INDUSTRIES INC. TEL: 631-952-2288 FAX: 631-951-2288 TOLL FREE: 800-645-9116 24-Hour Technical Support: 800-34-VICON (800-348-4266) UK: +44 (0) 1489 566300 WEB: vicon-security.com



Launching VAX

4.

- 1. Log into Windows using default credentials (login: VII; password: 1234).
- 2. Update VAX as necessary. Refer to Vicon's website.
- 3. Click on the VAX shortcut icon on the desktop. You can also go to the Start menu and click on the VAX icon inside the VAX folder.



The first time VAX is launched, an initial Configuration		
screen will display. Fill out all pertinent information,		
including username and password. Once that is done, the		
next time VAX is launched, a login screen will display.		
Enter the username/password that was previously created.		

💄 Initial Administrator	
Email Address	Required
Username	ADMIN
First Name	Required
Last Name	Required
System Language	English
Password	Required
Confirm Password	Required

🔒 Login		
Lusername		
# Password		
C Reset Password	✓ Login	

Valerus/VAX documentation has been provided on the system. A link is on the desktop. For the most updated documentation, visit Vicon's website at: https://www.vicon-security.com/products/valerusvms/ or https://www.viconsecurity.com/products/access-control/vaxoverview/



VICON INDUSTRIES INC. TEL: 631-952-2288 FAX: 631-951-2288 TOLL FREE: 800-645-9116 24-Hour Technical Support: 800-34-VICON (800-348-4266) UK: +44 (0) 1489 566300 WEB: vicon-security.com