



## AurorA VCR Playback and VCR Program Screen

### Playback Procedures

Playing back recorded video through an AurorA Multiplexer is easily accomplished with the following procedures. The AurorA99 procedure is identical.

1. Stop the VCR and rewind it to the approximate time to be reviewed.
2. On the AurorA, press the following keys in sequence: *Shift – Mode – 2*. The AurorA is now in *VCR Play (Decode)* mode, signified by the *VCR* indication in the lower left corner of the monitor.
3. Press *Play* on the VCR. The tape can be viewed playing back. All normal AurorA features, Freeze, Zoom Image, Sequencing, Multiscreen (except for P-I-P) are available during playback.
4. To return to *Live Viewing*, press *Shift – Mode – 1*.

### Accessing the VCR Programming Screen

1. On the AurorA, press the following keys in sequence: *Shift – Mode – 2*. The AurorA is now in *VCR Play (Decode)* mode, signified by the *VCR* indication in the lower left corner of the monitor.
2. On the AurorA, press, in sequence: *Menu – Down Arrow – Enter – Down Arrow – Menu – Menu*. This places the AurorA in the *No Decode* mode.
3. Follow the steps in the VCR Operator's manual to access the programming screen and complete the desired programming features.
4. After VCR programming is complete, on the AurorA, press in sequence: *Menu – Down Arrow – Enter – Up Arrow – Menu – Menu*. This places the multiplexer back in the AurorA decode mode.
5. To return to *Live Viewing*, press *Shift – Mode – 1*.